



# Broad Spectrum Disinfectant/Virucide Tablets

## Effervescent Disinfectant Tablets



Use **13.1g** tablets  
to produce  
**in-use gallons.**

Use **3.3g** tablets  
to produce  
**in-use quarts.**

**4**  
minutes  
1076 ppm

**Kills SARS associated Coronavirus 2  
on hard, non-porous surfaces.**

Disinfection is a process, not a product.

Step 1: Clean, Step 2: Disinfect\*

EnviroX's Broad Spectrum Disinfectant/Virucide Tablets are designed as part of a 2 product system. First, clean the surface with one of our proprietary hydrogen peroxide based multi-purpose cleaners. Then, complete your system with Broad Spectrum Disinfectant/Virucide Tablets where disinfection is needed.

**Broad Spectrum Disinfectant/Virucide Tablets deliver strong, easy-to-use, neutral pH disinfecting power that's effective against a broad range of microorganisms.**

Usage Table

**Effective for daily use against<sup>§</sup>:**

| Pathogen                                   | Required PPM | Contact Time |
|--|--------------|--------------|
| C. diff                                    | 4306         | 4 minutes    |
| TB   | 5383         | 4 minutes    |
| VRE  | 4306         | 4 minutes    |
| MRSA & GRSA                                | 4306         | 4 minutes    |
| Carbapenem resistant Klebsiella pneumoniae | 4306         | 4 minutes    |
| Candida auris                              | 4306         | 2 minutes    |
| Norovirus                                  | 2153         | 1 minute     |
| Hepatitis A, B & C Virus                   | 4306         | 1 minute     |
| Coxsackievirus                             | 4306         | 1 minute     |
| Avian Influenza A virus (H5N1)             | 4306         | 1 minute     |
| HIV-1 Type 1                               | 4306         | 1 minute     |

### Simplicity.

- Easy-to-use, single dose tablets for gallons and quarts delivers accurate strength solution every time eliminating "measure and pour" guesswork. No dispenser needed!
- Paired with the green cleaning formulations of EnviroX multi-purpose cleaners and the right application technology, Broad Spectrum Disinfectant/Virucide Tablets solve the time constraints and process problems of daily cleaning/disinfecting.
- Easy visual training materials. Train in Ten™ on only a few products instead of dozens. Learn the "right way" to disinfect—*only where needed.*

### Savings.

- Eliminate expensive specialty products and provide a healthier environment for your staff, students, customers.
- Reduce surface damage and staff injury, saving you on costly repairs and workers' compensation—*Safe to use on most water-safe surfaces. PPE not required for in-use dilutions.*†
- Easy, quick training means less time and money spent.
- Small tablet size equals multiple cost-savings: less storage space, lower shipping costs, easier handling and significant waste reduction.

### Amazing Results.

- Our unique 2 product system provides high performance cleaning and broad spectrum disinfecting to reduce the risk of hazardous cross-contamination on treated surfaces.
- Tough on C. diff spores, easy on surfaces, and designed for daily use—*Kills C. diff in 4 minutes!*‡
- Complies with surface disinfection recommendations from OSHA's Bloodborne Pathogen Standard.
- Effervescent sanitizing tablet for hard, non-porous food contact surfaces.

\*The CDC recommends a 2-step disinfecting process: Step 1: Clean, Step 2: Disinfect. †See product SDS for additional details. PPE not required under OSHA GHS but EnviroX recommended. §See product leaflet for complete list of specific kill claims, dilutions, and contact times.

## EnvirOx Broad Spectrum Disinfectant/Virucide Tablets

|                                      |  |
|--------------------------------------|--|
| <b>Description</b>                   | Disinfectant, Sanitizer, Virucide          |
| <b>Fragrance</b>                     | Slight chlorine-like                       |
| <b>Packaging</b>                     | 2 x 1 (13.1g) Bottles<br>6 x 1 (3.3g) Tubs |
| <b>Certification</b>                 | EPA: 71847-6-69268                         |
| <b>Shelf Life</b>                    | 3 Years                                    |
| <b>Tablet Dissolve Time in Water</b> | 2.5-3 minutes per tablet                   |

Pair Broad Spectrum Disinfectant/Virucide Tablets with one of our multi-purpose cleaners for a complete, low-cost, 2 product cleaning and disinfecting system. Remember, **disinfection is a process, not a product.**

### STEP 1: CLEAN



EPA Reg. No. 69268-1

### STEP 2: DISINFECT



## Disinfecting with Envirox Broad Spectrum Disinfectant/Virucide Tablets couldn't be easier!

Based on the kill claim you require—simply refer to the Usage Table to determine the number of tablets needed for that claim, add the tablet(s) to the recommended volume of water, and you're ready to go.

| 13.1g Tablet Size                      |                                    |
|--|------------------------------------|
| Solution ppm (mg/L) Available Chlorine | # of Tablets per 1 Gallon of Water |
| 1076                                   | 1                                  |
| 2153                                   | 2                                  |
| 4306                                   | 4                                  |
| 5382                                   | 5                                  |

For Use in Gallons

| 3.3g Tablet Size                       |                                   |
|--|-----------------------------------|
| Solution ppm (mg/L) Available Chlorine | # of Tablets per 1 Quart of Water |
| 1076                                   | 1                                 |
| 2153                                   | 2                                 |
| 4306                                   | 4                                 |
| 5382                                   | 5                                 |

For Use in Quarts

Check out the NEW Envirox training portal: [www.enviroxclean.com/training](http://www.enviroxclean.com/training)



### Ready to achieve simplicity & savings?

To get a custom cost comparison, live product demo or to install a no-risk trial, contact your Envirox sales representative today!

Need help?  
Contact us.

1-800-281-9604

[enviroxinfo@enviroxclean.com](mailto:enviroxinfo@enviroxclean.com)

[www.enviroxclean.com](http://www.enviroxclean.com)

**ENVIROX**

1938 E. Fairchild, Danville, IL 61832

©2022 Envirox, LLC, Danville Illinois, USA



9-855-123  
V1-02152022